

INSTALLATION INSTRUCTIONS

STEP 1. BEGIN THE INSTALLATION BY OPENING THE HOOD AND REMOVING THE (4) PHILLIPS HEAD SCREWS FROM THE TOP OF THE GRILLE. UNHOOK THE (2) RETAINING CLIPS AT THE BOTTOM AND REMOVE THE GRILLE FROM THE VEHICLE.

STEP 2. LOCATE THE 10MM BOLTS THAT CONNECT THE BUMPER TO THE BUMPER SUPPORT BRACKETS. THE BOLTS ARE LOCATED ON THE BACK EDGE AT THE TOP OF THE BUMPER. REACH THROUGH THE OPENING IN THE FACE OF THE BUMPER AND REMOVE THE BOLTS (1) PER SIDE CLOSEST TO THE CENTER OF THE VEHICLE.

STEP 3. LOOSELY ATTACH 1131AD AND 1131AP UPPER BRACKETS TO THE BUMPER SUPPORT BRACKETS USING THE FACTORY 10MM BOLTS.

STEP 4. RE-ATTACH THE GRILLE TO THE FRONT OF THE VEHICLE.

STEP 5. REMOVE THE 12MM BUMPER BOLTS (2) PER SIDE FROM THE FACE OF THE BUMPER.

STEP 6. POSITION 1131BD AND 1131BP LOWER BRACKETS OVER THE TOW HOOKS AND ATTACH TO THE FACE OF THE BUMPER USING THE FACTORY 12MM BUMPER BOLTS.

STEP 7. ATTACH THE GRILLE AND BRUSH GUARD ASSEMBLY TO THE OUTSIDE OF THE MOUNTING BRACKETS USING THE 3/8" X 1" BUTTON HEAD BOLTS FOR THE UPPER BRACKETS AND THE 3/8" X 1 1/4" HEX HEAD BOLTS FOR THE LOWER BRACKETS. ALIGN WITH FRONT OF VEHICLE AND TIGHTEN ALL NUTS AND BOLTS.

