

# Textron Havoc Seats

## Install Instructions



**Read through all of the instructions completely before beginning the install.**

**Parts Included:**

2 x PRP Seats Suspension Seats for Textron Havoc

**Hardware Included:**

8 - 1/4" x 20 x 1" Bolts

8 x 1/4" USS Flat Washers

8 x small screws, nuts and washers to attach pull strap

**Tools required:**

Phillips head screwdriver

7/16 socket or wrench

5/16 open end wrench

3/16 drill bit

**Remove all parts from the box and unwrap completely using the packaging to lay out the pieces.**

**Time:**

Approx 15 minutes.



### 1. Remove Stock Seat Base

Remove the Stock Havoc Seats by releasing the handle on the back of the seat.

Once the stock seat is out. Remove the 4 bolts that connect the plastic base from the bottom of the stock seat.



### 2. Install Seat Base

Place the plastic base on the bottom of the PRP Seat, and install with with our supplied (4 qty) 1x4"x20x1" bolts and (4 qty) USS Flat Washers. \*Make sure that the release handle is still on the rear of the seat.

**IMPORTANT:** Only tighten the bolts by hand.



### 3. Attach Pull Strap

Your PRP seat doesn't have an open center like the stock seat does, so it can be hard to reach the handle to release the seat. To fix this issue, we designed a pull strap on the back of our PRP seats, that connects to the release handle. Pull up on the strap behind the headrest, and it will release the seat as usual.

Line up the the 'T' at the end of the pull strap, and drill 2 small holes into the plastic release handle. Using the hardware attached to the outside of one of the seats in a RED BAG and a 5/16 wrench, attach the pull strap on the back of the seat to the under side of the latch on the stock seat base.



#### 4. Re-Install Seat

Place the PRP Seat into the vehicle the exactly like you do the stock one. Hook the lip of the plastic base under the metal bar in the front, and guide the pin into the locking mechanism in the rear.



#### 5. Repeat Steps On Other Side

Repeat Steps 1-4 on the other seat. Installation is exactly the same on driver and passenger sides.



#### 6. Aaaaaand, your done!

Congratulations! Your new PRP Seats is installed and ready to use.

If you have any questions or experience issues, please contact your retail outlet first for help. However, the staff at PRP is always happy to help at **1-800-317-6253**.

**Thank you! Ride Safe!**